

# Grid-Guard

## Grid-Guard Rock Shield Installation Procedures

### Pads:

1. Custom cut pads should be wrapped fully around the circumference of the pipe, ensuring full coverage. Overlap should be from 4" to 6".
2. Ensure that the overlap "lip" is facing downwards when securing to the pipeline.
3. Secure pad to pipe with a polyester filament tape at least  $\frac{3}{4}$ " in width.
4. Place pads end to end with a 2" to 4" overlap between pads down the pipeline.

### Rolls:

1. Rolls should be adequate width to fully wrap around the circumference of the pipe. Overlap should be 4" to 6".
2. Ensure that the overlap "lip" is facing downwards when securing to the pipeline.
3. Secure rolls to pipe with a polyester filament tape at least  $\frac{3}{4}$ " in width.
4. Place rolls end to end with a 2" to 4" overlap between rolls down the pipeline.

